Single Acrylic Screens

Post Style Bracket



Trendway>



Easily convert your open plan office to a more secluded environment with Trendway's new acrylic screens. There are many options to choose from to quickly retrofit your space when it's time to get your team back to the office – safely.

Single Screens | Post Style Bracket

A single acrylic panel screw mounts onto the work surface. With heights from 24" to 36" and widths of 24" to 72", adapt almost any workstation with division to minimize risk. Available in frosted and clear options for varying levels of privacy. Optional 4" access slot is also available.






left screen with 4" access slot option

Single Screen | Post Style Bracket | Screw Mount

Dimensions		Insert Material		Catalog #
Width	Height	Clear Acrylic	Frosted Acrylic	
24" 30" 36" 42" 48" 54" 60" 66" 72"	24"	\$420 \$430 \$499 \$510 \$520 \$530 \$540 \$684 \$695	\$456 \$495 \$573 \$575 \$580 \$825 \$835 \$840 \$851	SCNSMPS2424 SCNSMPS3024 SCNSMPS3624 SCNSMPS4224 SCNSMPS4824 SCNSMPS5424 SCNSMPS6024 SCNSMPS6624 SCNSMPS7224
24" 30" 36" 42" 48" 54" 60" 66" 72"	30"	\$420 \$447 \$499 \$510 \$520 \$578 \$590 \$684 \$695	\$494 \$648 \$655 \$660 \$665 \$1,288 \$1,295 \$1,310	SCNSMPS2430 SCNSMPS3030 SCNSMPS3630 SCNSMPS4230 SCNSMPS4830 SCNSMPS5430 SCNSMPS6030 SCNSMPS6030 SCNSMPS6630 SCNSMPS7230
24" 30" 36" 42" 4" 54" 60" 66" 72"	36"	\$499 \$510 \$658 \$670 \$680 \$685 \$695 \$1,000 \$1,000	\$571 \$648 \$803 \$805 \$810 \$1,288 \$1,295 \$1,300 \$1,310	SCNSMPS2436 SCNSMPS3036 SCNSMPS3636 SCNSMPS4236 SCNSMPS4836 SCNSMPS5436 SCNSMPS6036 SCNSMPS6036 SCNSMPS6636 SCNSMPS7236






Available:

- With or without 4" access slot
- Clear or Frosted acrylic
- Standard or Premium (+\$12) color bracket paint finishes


Acrylic Screen Dimensions | Post Style Bracket




Model SCNSMPS4830 48"Wx30"H

Work surface needs to be a minimum of 44.625"W to fit this screen model.

All screen dimensions are identical between adhesive and screw mounting methods.





Cleaning Instructions for Acrylic Screen

First time setup: Do not attempt to clean immediately after removing the protective paper because the static electricity will attract dust and particles. Wait a day for the static to dissipate before cleaning.

Step 1

Begin by removing excess dust or dirt from the surface of the acrylic with an air hose or blow dryer set to its coolest setting (never heat acrylic). Hold the blow dryer at a 45-degree angle several inches away from the acrylic and run side-to-side down the surface. Wipe any remaining dust with a soft, lint-free cotton microfiber cloth.

Step 2

Once excess grime has been blown away, spray a nonabrasive acrylic cleaner, such as Brillianize or Novus No. 1 onto a one- or two-foot-square section of acrylic. (For an on-hand alternative, a solution of mild dish soap and water works well too.). Never use abrasive cleaners or anything containing Ammonia such as Formula 409°, Windex° or Fantastik°. Ammonia will cause your acrylic to get cloudy and you can't reverse the effects. Bleach solutions and disinfectants are not recommended and can cause damage to the acrylic.

Once the cleaner has been applied, use a soft, lint-free cotton microfiber cloth to gently wipe the surface down, again being careful to make contact only with the portion of the surface that already has cleaner on it. Continue applying the cleaner and wiping it off in small sections until you've finished the entire surface. Do not use a paper towel to clean acrylic because it can cause scratching.



